DART SERVICE INSTRUCTION

TO AMEND INSTALLATION INSTRUCTIONS IIN-D130-701 REV. G AND INSTRUCTIONS FOR CONTINUED AIRWORTHINESS ICA-D130-701 REV. 5 OR LATER APPROVED REVISION

REF. TCCA STC: SH94-14 REF. FAA STC: SR00213NY REF. EASA STC: 10016996 REF. ANAC STC: 2007S03-03

1.0 PURPOSE

The purpose of this Dart Service Instruction (DSI) is to provide instructions for the installation of D5626-1 bushings to prevent mounting hole elongation.

This DSI is applicable to D130-701-041 Basket installations at CHG 006 or earlier (D3177-041/-043 Fwd/Aft Bracket assemblies) and D130-701-043 Basket installations at CHG 010 or earlier (D4039-041/-043 Fwd/Aft Bracket Assemblies). The intent of this DSI has been incorporated into D130-701-041 @ CHG 007 and subsequent and D130-701-701-043 @ CHG 011 and subsequent.

2.0 PROCEDURE

To remove and re-install the Heli-Utility-Basket or brackets, refer to the sections of ICA-D130-701 called out in the following procedure.

- Remove the D130-701-041 Heli-Utility-Basket and D3177-041/-043 Fwd/Aft Brackets per Section 25.1.
- Remove the D130-701-043 Heli-Utility-Basket and D4039-041/-043 Fwd/Aft Brackets per Section 25.3 or Section 25.5 as applicable.
- 3. On D3177-041/-043 or D4039-041/-043 Fwd/Aft Brackets, enlarge the 2 mounting holes by drilling/reaming to ϕ 7/16" (ϕ 0.4375 +0.0000/-0.0005 in). Ensure the holes are drilled/reamed straight and perpendicular to the bracket as shown in Figure 1. Deburr holes.
- 4. Apply Alodine 1200/1201 per MIL-C-5541 to the bare holes in the brackets.
- 5. Cool/freeze the supplied D5626-1 Bushings. Install the bushings in the drilled/reamed holes. The Bushings are designed with an interference fit so pressing may be required. Allow the D5626-1 bushings to warm up in the mounting holes on the D3177-041/-043 or D4039-041/-043 Fwd/Aft Brackets. Make sure the bushings remain flush with outer surface as shown in Figure 1. Verify that the ID of the bushings after installation is \emptyset 0.257. Ream as required. Caution: Take appropriate safety precautions when handling the cold bushing.
- 6. Mask D5626-1 Bushing holes and touch up prime/paint per paragraph 5.2.4 of ICA-D130-701.
- Re-install the D130-701-041 Heli-Utility-Basket and modified D3177-041/-043 Fwd/Aft Brackets per Section 25.2.
- 8. Re-install the D130-701-043 Heli-Utility-Basket and modified D4039-041/-043 Fwd/Aft Brackets per Section 25.4 or Section 25.6 as applicable.
- Update aircraft logbook to indicate installation of the DSI 9798-011 Bushing Kit.

3.0 WEIGHT AND BALANCE

This DSI has a negligible effect on Weight & Balance.

CANADA
DEPARTMENT OF TRANSPORT
AIRCRAFT CERTIFICATION
BRANCH
DAO # 01-O-01

APPROVED


BY:
D. SHEPHERD (DE # 02)

DATE:
CERT. NO.:
ISSUE NO.:
7

	Α	NEW ISSUE; REF CAR17-189			RF	18.03.05
	REV.			DESCRIPTION	BY	DATE
	DESIGN		RF	DART AEROSPACE LTD		TD
	DRAWN		RF	HAWKESBURY, ONTARIO, CANADA		
	CHECK	ED	WK	DRAWING NO.		REV. A
:	MFG. APPR.		N/A	DSI 9798		SHEET 1 OF 2
)	APPROVED		HS "	TITLE		SCALE
:	DE APP	R.	DS #	BUSHING KIT		NTS
: [DATE 18.03.05			COPYRIGHT © 2018 BY DART AEROSPACE LTD. THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.		

4.0 PARTS LIST

QTY -011	PART NUMBER	DESCRIPTION
Х	DSI 9798-011	BUSHING KIT
4	D5626-1	BUSHING






FIGURE 1: D5626-1 BUSHING INSTALLATION INTO D4039-041 BRACKET DIMENSIONS FOR D4039-041 SHOWN (DIMENSIONS FOR D3177-041/-043, D4039-043 SIMILAR)

	DESIGN	RF	DART AEROSPACE LTD		
_	DRAWN	RF	HAWKESBURY, ONTARIO, CANADA		
Ð	CHECKED	WK	DRAWING NO.	REV. A	
\geq	MFG. APPR.	N/A	DSI 9798	SHEET 2 OF 2	
8	APPROVED	HS . ,	TITLE	SCALE	
H.	DE APPR.	DS-	BUSHING KIT	NTS	
AP	DATE 18.0	3.05	COPYRIGHT © 2018 BY DART AEROSPACE LTD. THIS DOCUMENT IS PRIVATE AND COMFERENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.		